



EN	INSTALLATION
DE	INSTALLATION
FR	INSTALLATION
SE	INSTALLATION
CZ	INSTALACE
DK	INSTALLATION
ES	INSTALACIÓN
FI	ASENNUS
NL	INSTALLATIE
NO	INSTALLASJON
PT-BR	INSTALAÇÃO
IT	INSTALLAZIONE
PL	INSTALACJA



BINAR | NEO 30™

Innovation beyond gravity

EN Delivery
DE Lieferung
FR Livraison
SE Leverans

CZ Dodávka
DK Levering
ES Entrega
FI Toimitus


NL Levering
NO Levering
PT-BR Entrega
IT Consegna
PL Dostawa



EN Safety
DE Sicherheit
FR Sécurité
SE Säkerhet

CZ Bezpečnost
DK Sikkerhed
ES Seguridad
FI Turvallisuus


NL Veiligheid
NO Sikkerhet
PT-BR Segurança
IT Sicurezza
PL Bezpieczeństwo



EN Check
DE Überprüfen
FR Vérifier
SE Kontrollera

CZ Zkontrolovat
DK Kontrollere
ES Comprobar
FI Tarkista


NL Controleren
NO Kontroller
PT-BR Verifique
IT Controllo
PL Sprawdz



EN Unlock batteries
DE Batterien entsperren
FR Déverrouiller les
batteries
SE Lås upp batterier
CZ Odemknout baterie

DK Lås batterier op
ES Desbloquear baterías
FI Avaa akku
NL Ontgrendel de
batterijen




NO Låse opp batteriene
PT-BR Desbloquear
baterías
IT Sblocco delle batterie
PL Odblokuj baterie





EN Installation
DE Installation
FR Installation
SE Installation
CZ Instalace

DK Installation
ES Instalación
FI Asennus
NL Installatie
NO Installasjon

PT-BR Instalação
IT Installazione
PL Instalacja








EN Test
DE Test
FR Test
SE Test

CZ Test
DK Test
ES Prueba
FI Testi

NL Test
NO Test
PT-BR Teste
IT Collaudo
PL Test



Contact information manufacturer

Binar Quick-Lift Systems AB

Hedekullevägen 24

461 38 TROLLHÄTTAN

Tfn: +46 (0)520 – 47 40 00

E-mail: info.neo@binar.se

E-mail: service.neo@binar.se